

**Sx80PI and Sx80PIX**  
**OPTIONAL PORT COVER**  
**INSTALLATION INSTRUCTIONS**

1. Remove the 11 screws securing the grille to the enclosure and remove the grille.
2. Place supplied foam tape around the outside perimeter of each of the two ports.
3. Place port cover over port and foam tape. Secure port cover directly to cabinet by using the supplied self-tapping screws (two per port cover).
4. A bead of outdoor black RTV can be placed around each of the edges of the port covers if additional weather protection is desired.
5. Re-attach grille to enclosure.

535277

**Sx80PI and Sx80PIX**  
**OPTIONAL PORT COVER**  
**INSTALLATION INSTRUCTIONS**

1. Remove the 11 screws securing the grille to the enclosure and remove the grille.
2. Place supplied foam tape around the outside perimeter of each of the two ports.
3. Place port cover over port and foam tape. Secure port cover directly to cabinet by using the supplied self-tapping screws (two per port cover).
4. A bead of outdoor black RTV can be placed around each of the edges of the port covers if additional weather protection is desired.
5. Re-attach grille to enclosure.

535277

**Sx80PI and Sx80PIX**  
**OPTIONAL PORT COVER**  
**INSTALLATION INSTRUCTIONS**

1. Remove the 11 screws securing the grille to the enclosure and remove the grille.
2. Place supplied foam tape around the outside perimeter of each of the two ports.
3. Place port cover over port and foam tape. Secure port cover directly to cabinet by using the supplied self-tapping screws (two per port cover).
4. A bead of outdoor black RTV can be placed around each of the edges of the port covers if additional weather protection is desired.
5. Re-attach grille to enclosure.

535277